

Electronics > Schematic diagrams > Metal detectors > White's Surfmaster P.I. metal detector

White's Surfmaster PI schematic diagram

White's **Surfmaster PI** is a good quality, fully waterproof, lightweight metal detector with an exceptional depth in saltwater or mineralized but such use is not advised as -- like all PI (Pulse Induction) designs -- there is no effective discrimination of ferrous objects. Runs on eight

ch beaches, in the surf or shallow diving. It works inland too,

Complete



xTool D1 Pro 20W

Breaking Through the
Diode Laser Limit










Fig. 1: White's Surfmaster PI metal detector schematic diagram - (2000x935 PNG)

- Nominal capacitor range of 0.001-0.39uF = polyester film.
- Nominal capacitor range of 0.047-1uF = stacked polyester film.
- ST = Stacked polyester (Panasonic "V" series) +/-5%.
- Simple mod: If TIP32C (Q2) gets excessively hot, use an IRF9640 MOSFET instead. Experiment with different values for R6 to find the optimal value (I use a 390 ohm resistor). Temporarily substitute R6 for a trim potentiometer $(470\Omega \text{ or } 1k\Omega)$ to find the optimal dumping resistor for your coil.



Fig. 2: White's Surfmaster PI metal detector

More metal detector schematics:

Heathkit Cointrack Gd-1190 Metal Locator
Heathkit Groundtrack GR-1290 VLF metal detector
White's Classic I metal detector schematic
Simple BFO metal detector schematic diagram

- R1, R10, R22, R35: 100kΩ
- R2: 3.3kΩ
- R3, R7, R8, R13, R14, R21, R33: $1k\Omega$
- R4, R5: 100Ω
- R6: 220Ω 1/2 W
- R9: 1MΩ
- R11, R20, R23, R32: 22kΩ
- R12, R27: 10kΩ
- R15, R16, R17: 220kΩ
- R18: 47kΩ
- R26, R29: 51kΩ
- R28: 210kΩ
- R34: 150Ω
- R25: 50kΩ trim potentiometer
- R10: $100k\Omega$ trim potentiometer
- R33: $1k\Omega$ trim pot. (Volume control)
- P1: 10kΩ potentiometer (THRESH)
- P2: 100kΩ potentiometer (DISC)

Coil:

Note: It's best to use the original Surfmaster coil for optimal performance, but you can experiment with different turns, wire gauge and coil diameters, shielding...

A reasonable depth and sensitivity can be obtained with a 23cm diameter coil, 20 turns made with 0.5mm (24 gauge) standard copper enamel coated wire.

- C1: 22nF
- C2: 1000uF/25V electrolytic
- C3, C4, C8, C16: 100nF
- C5, C6, C7: 470nF
- C9, C10, C11, C12: 1nF
- C13, C14, C15: 220uF/10V electrolytic

Transistors:

- Q1: 2N3906 (PNP silicon transistor)
- Q2: TIP32C (PNP silicon power transistor)
- Q6: MPSA13 (NPN Darlington transistor)

Diodes:

- D1, D2, D3: 1N4148 (Switching diodes)
- D6: 1N4001 (Rectifier diode)
- D7: 1N5819 (Schottky Barrier Rectifier)
- D5: 1N755 (7.5V Zener diode)

Integrated circuits:

- U1: TLC555 (LinCMOS timer IC)
- U2: NE5534 (Single Low Noise Op Amp)
- U3: LM358 (Low Power Dual Op Amp)
- U4: MC14093B (Quad Schmitt trigger)
- U5: 78L05 (5V Positive Voltage Regulator)
- U6: ICL7660 (CMOS switched-capacitor voltage converter)
- U7: CD4066 (Quad Bilateral Switch)





Complete your collection eBay

<u>Electronics</u> > <u>Schematic diagrams</u> > <u>Metal detectors</u> > White's Surfmaster PI schematic diagram

Where to buy <u>resistors</u>, <u>capacitors</u> and <u>LEDs</u> online

